


## IM330, IM350 - Loading (Installing) Rates

The following conditions must be met before loading (installing) rates:

- The customer must have a rate protection contact.
- The machine must be declared.


### Loading (Installing) Rates:

1. Press the "MENU" button.




2. Press the down arrow button until "Online Services" is highlighted.

- Press the "OK" button to access the next step.



3. Press the down arrow button until "Generic Call" is highlighted.  
- Press the "OK" button to access the next step.



4. The server call consists of:


- Preparing for the call
- Dialing the call
- Transaction in progress

DO NOT INTERRUPT THIS PROCESS.



5. The server call finished successfully.

- Press the "OK" button to access the next step.



6. Press the back button several times until the Homescreen is displayed.

