

# WJ60, WJ65, WJ90, WJ95, WJ110 – Changing the Default Stamp Value from \$0.39 to \$0.41



## HASLER

“WJ60, WJ65, WJ90, WJ95, WJ110” Default Value

### Default Stamp Value:

The Default Stamp Value allows the user to determine the default postage value that is displayed each time the meter is powered on or returns from locked mode.

1	<p>If the meter shows last years rate after installing the new rate card, then the Default Stamp Value has to be changed. Press the Lock button to display the main screen. Press the SUPERVIS Button and enter the Supervisor password (9430).</p>	
2	<p>Select Setup using the up &amp; down arrows. Then press OK.</p>	
3	<p>In the SETUP menu use the up &amp; down arrows to select “Default Stamp Value”. Then press the OK button.</p>	
4	<p>You will see a box that contains “Default Stamp Value” and \$0.00 value. Enter the new desired default value and press OK. Note: To set \$0.41 as a default, enter 410. Then press OK.</p>	
5	<p>From the SETUP screen, you should see the updated value. Press the lock button to return to the Neopost main screen. Enter User to assure the Default Stamp Value has been changed.</p>	